## CABINET USE & CARE



CERAMIC

Spray with mild, soapy solution or water and vinegar mixture. Wipe immediately with a clean rag to remove the soap residue. Do not let water sit on the hardware.

WOOD

Rub with a damp rag or cloth.



Spray with glass cleaner or water and vinegar solution. Wipe clean with rag or cloth.



Spray with mild, soapy solution or water and vinegar mixture. Wipe with a clean rag to remove the soap residue.

Alternate method: Remove hardware using a screw driver. Soak in a soapy solution for several hours or overnight. Rinse and thoroughly dry prior to installation.

## CABINET USE & CARE





Rub with a damp rag or cloth.

Spray with glass cleaner or water and vinegar solution. Wipe clean with rag or cloth.



Spray with mild, soapy solution or water and vinegar mixture. Wipe with a clean rag to remove the soap residue.

Alternate method: Remove hardware using a screw driver. Soak in a soapy solution for several hours or overnight. Rinse and thoroughly dry prior to installation.