
•	1
•	hanny
$\checkmark$	
	hapny

**TWIST KNOB** 

Tech Spec



## CARE INSTRUCTIONS:

Gentle is key. Clean your hardware with a soft, damp cloth, and wipe completely dry. Do not leave any water or soap residue on your product. Never use any chemicals or harsh over-the-counter cleaners, as these will strip the finish and void your warranty.